





Clock Instructions (2-1/16" • 2-5/8" • 3-3/8")

SPEEDHUT®

ORDERS WITH 1-2 GAUGES

ORDERS WITH 3+ GAUGES

OR



ATTENTION: 5 amp In-Line Fuse recommended for +12 Keyed Ignition.


INSTALLATION

- 1 DISCONNECT your vehicle's negative (-) battery cable.
- 2 CONNECT the gauge wiring.
- 3 MOUNT your gauge to the panel using the spin lock ring.
- 4 RECONNECT your vehicle's negative (-) battery cable.

WHITE: +12v Dash Lighting (Pointer Lighting)
 BLACK: Ground
 RED: +12v Battery Voltage (Main Gauge Power, connect to constant 12v.)

ATTENTION: Power Draw = 0.05 amp.

WHITE: +12v Dash Lighting (Dial lighting)
 BLACK: Ground



SETTING CLOCK TIME

- 1 PRESS and hold button to rotate clock hands to current time.

LIFETIME WARRANTY

We take pride in the products we make and offer a Lifetime Warranty on gauge electronics and a 5-year warranty on hardware for every gauge, tachometer and shift light purchased since Jan 1, 2006. Every SPEEDHUT product is built for a lifetime of service, and we warrant to the person who originally purchased the product that all SPEEDHUT products will be free from defects in workmanship and materials for their applicable warranty period. If a defect occurs during the warranty period as the result of the product's intended use, we will repair or replace the defective product or part, to our discretion. The warranty does not cover defects caused by third-party modifications, repairs or replacement parts. Any holes, scratches, normal wear and tear, and the natural breakdown of colors and materials over extended time and use are not warranted.

CONTACT US

Support@Speedhut.com
 801-221-1460 (9a-4p MST)
 FAQ - Speedhut.com/faq.i
 www.Speedhut.com